



Fitting instructions for the mosquito net

Thank you for purchasing our mosquito net.

Inside the packaging, there are:

1 x mosquito net with poppers fitted on the edges

The same number of screw popper studs

Our net can fit the original holes predrilled on original Westfalia campers, but it is better to fit the enclosed screw studs to the matching locations based on the poppers location on the net to achieve better effects.

A. Fit onto old popper studs:

If you have prefitted popper studs in reasonable condition and you want to use them, you can use our net directly onto the old popper studs.

B. Fit new popper studs:

1. Open the net. Place it against the door/gate indicated on the products label with the popper dome heads facing inside and the female rings facing outside the camper.
2. Use a pen to mark all popper locations onto the inner panel/metal work where they are properly in line with the poppers on the netting border.
3. Please check you are happy that the marks you have made line up neatly with the popper on the netting border. It should fit snug against the panels to prevent the entry of insects. Adjust accordingly.
4. It is suggested that you drill the four corner holes first so that any adjustments to the position of other holes can be done.
5. Please check before drilling any holes that your mosquito net lines up with any marks you have made.